

DAYLIGHT SAVING TIME (D.L.S.)

STEP 22 DAYLIGHT SAVING START (OR SUMMERTIME START)

You can specify either by DATE or by WEEKNUMBER. The change of time (from 02.00 → 03.00) will happen on the Sunday (last day of the programmed week).



To specify by weeknumber, select "00"
To specify by date, select a month 01-12



If selected above:
- "00", select a weeknumber 01-52
- "01-12", select a date 01-31
(Do not set 02 29, February 29th)

STEP 23 DAYLIGHT SAVING END (OR WINTERTIME START)

The change of time (from 03.00 → 02.00) will happen on the Sunday (last day of the programmed week).

If selected by weeknumber at step 22,



set the weeknumber (01-52)

If selected by DATE at step 22,



set month (01-12) and date (01-31)
(Do not set 02 29, February 29th)

REMARK : To switch OFF this daylight saving feature, programme "00:00" in step 22 (default setting).
Automatically step 23 will be skipped.

NOTE : To have an automatic summer- and wintertime change EVERY year, happening on the last Sunday of a specific month, programme as follows :

Take the number of days that the month counts.
Subtract 6 from this number and programme that date.
(Do NOT count February 29th)
e.g. September counts 30 days, minus 6. Programme the 24th.
By doing so, it will not be necessary to change your set data every year.

The scheme on the following page gives an overview of some popular dates.

SOME POPULAR D.L.S. DATES :

D.L.S. start or summertime start

<u>DATE</u>	<u>SET</u>	<u>SETTING</u>
- Last Sunday of March	March 25 th	03 25
- Last Sunday of April	April 24 th	04 24
- Last Sunday of September	September 24 th	09 24

D.L.S. end or wintertime start

<u>DATE</u>	<u>SET</u>	<u>SETTING</u>
- Last Sunday of October	October 25 th	10 25
- Last Sunday of September	September 24 th	09 24
- The Sunday following the 4 th Saturday of October (U.K.)	October 23 th	10 23
- Last Sunday of March	March 25 th	03 25

QUICK HOUR CHANGE (Manual D.L.S. adjustment)

To change quickly the hour displayed, without selecting step 13, do as follows (while being in normal mode) :

To increment the time displayed by 1 hour (D.L.S. start or summertime start), keep the "Yes"-key pressed while sliding the program switch to program mode.

To decrement the time displayed by 1 hour (D.L.S. end or wintertime start), keep the "No"-key pressed while switching to program mode.

CAUTION : When changing in this way, only the time displayed will change, NOT THE DATE

e.g. Friday 23:30
↓
INC
↓
Friday 00:30 NOT Saturday 00:30